

UltraRib Installation Procedure

- ◆ Cut UltraRib to desired height.
- ◆ Run a bead of Silicone around outside perimeter of tank manway and fill in previous screw holes.



- ◆ Locate UltraRib over tank manway so UltraRib sits flush with top of tank manway.
- ◆ Screw Ultra Rib to manway in four locations using screw and gasketed washers.



- ◆ Silicone inside of UltraRib and tank.



4 screws with gasketed washers
orientated every 90 degrees.

- ◆ Repeat for other manway.